

Bra Sizing Guide

CURVESSENCE™ 3 D BRA TECHNOLOGY REPLACING UNDERWIRES

FITTING CURVESSENCE BRAS

All Silent Assembly Bras use the world's leading bra technology -**CURVESSENCE™**. **CURVESSENCE™** replaces metal underwires with a 3D shaped "Rib" made from an engineered Nylon.

The **CURVESSENCE™** 3D ribs offer a support structure that moulds around your body for an incredibly comfortable all day fit.

CURVESSENCE™ bras fit more comfortably than underwires as they are designed to fit around the bust and the left and right curvature of the female body respectively.

The revolutionary new shape of **CURVESSENCE™** offers a superior fit because there is no forced underwire contortion, unlike traditional underwires where the back wings are used to force a flat wire around the torso.

BRA MEASUREMENT GUIDE

BODY SIZE	AU/NZ		10	12	14
	EU/ASIA		70	75	80
	UK/USA		32	34	36
	FRANCE		85	90	95
	ITALY		1	2	3
Underbust Measurement range (in cm)			67-72	72-77	77-82
Overbust Measurement range (in cm)					
B			84-86	89-91	94-96
C			86-88	91-93	96-98
D			88-90	93-95	98-100
DD (E) Europe			90-92	95-97	100-102

INTERNATIONAL SIZE CONVERSION CHART

UK	32B	32C	32D	32DD	34B	34C	34D	34DD	36B	36C	36D
French	85B	85C	85D	85E	90B	90C	90D	90E	95B	95C	95D
European	70B	70C	70D	70E	75B	75C	75D	75E	80B	80C	80D
Australia	10B	10C	10D	10DD	12B	12C	12D	12DD	14B	14C	14D

HOW TO MEASURE



Overbust Measurement

Hold the tape measure level around the fullest part of the bust.

Underbust Measurement

Hold the tape measure level and firmly, directly beneath the bust.

Hip Measurement

Hold the tape measure level around the fullest part of the hips.